

# Unlock Instructions by EarthWizeCellular.com

---



## How to enter my Unlock Code on a Motorola Cell Phone?

### Motorola A1000 and other A models

1. Click on the phone icon.
2. Enter the following: \*\*057\*
3. Phone displays "Locking Enter Personalization"
4. Enter the Unlock Code.
5. Click Ok.

### Motorola L6i & L7i (not L6 and L7 without "i")

1. Press and hold the "\*" key and enter code: 787090
2. The mobile displays: "Menu Network"
3. Choose 'yes' and then press OK.
4. The mobile will ask you for a code.
5. Enter the Unlock Code.

### Motorola 3G

1. If your phone is on a 3G network enter: \*\*057\*
2. Then enter the Unlock Code into the phone.

### Motorola CDMA & TDMA

1. Press 74663 # [Menu] [Menu] and you will be asked for a 'Subsidy Code'.
2. Enter the Unlock Code you received.
3. Your phone is now unlocked.

### Motorola MPX

1. Switch ON your phone with a Non - Allowed SIM card
2. If phone is asking for NETWORK PIN enter the NETWORK PIN we sent you, or if phone is asking for SERVICE PROVIDER PIN. Enter the SERVICE PROVIDER PIN we sent you. Your phone is now unlocked. If instead your phone is asking for NETWORK PUK please do the following:
  1. Power on the phone with the original card in and wait till phone is fully powered on and you have access to menu.
  2. Enter: \*#\*364# and press green button
  3. You will get an error message and after that you will see the Engineering menu.
  4. Click Options
  5. Click GSM Test
  6. Select Send AT command
  7. Now you will see a new window Saying "Send AT Command"
  8. Type AT+CLCK="PN",0,"[SERVICE PROVIDER PIN or NETWORK PIN]" and press send
  9. If you get Response "0 []" the phone is unlocked.

# Unlock Instructions by EarthWizeCellular.com

---

If you get 1 error, then make sure you have typed the code correctly and try the other code by doing the following:

1. Switch your phone off.
2. Take battery out.
3. Put battery back in.
4. Power on the phone and leave it for 40 minutes to 5 hours until the message "Enter NETWORK PUK" is gone.
5. Now enter the code received from us and 00000000 (eight zero's) as a new password.

Then,

1. Power on the phone with the original SIM card in and wait till phone is fully powered on and you have access to menu.
2. Enter: `*#*#364#` and press the green button.
3. You will get an error message and after that you will see the Engineering menu
4. Click Options
5. Click GSM Test
6. Select Send AT command
7. Now you will see a new window Saying "Send AT Command"
8. Type `AT+CLCK="PP",0,"[SERVICE PROVIDER PIN or NETWORK PIN]"` and press send
9. If you get Response "0 []" phone is unlocked
10. If you get 1 error, then make sure you have typed the code correct and try the other code.

If you do not have the original card or if the original card is not accepted because you flashed the phone with other firmware, then we cannot help you

**All other Motorola not listed above.**

1. Switch ON your phone with a not allowed SIM Card,
2. Phone show "Enter Special Code",
3. You can now enter the Unlock Code we send to you.

WARNING: If one of these messages appear -

- "Contact Service Provider"
- "Tampert Alter"
- "Wait before enter special Code"
- "Contact Service'

It is because someone has already enter too many wrong codes, you just have to leave the phone ON theses errors messages and after 40 min to 2 hours maximum the message "Enter Code Special" will appear again!