

# Unlock Instructions by EarthWizeCellular.com

---



## How to enter my Unlock Code on an LG Electronics Cell Phone?

### LG Incite CT-810

1. Insert a SIM Card from the original network.
2. Enter: 2945##810#
3. Display will show the unlock menu.
4. Enter Unlock Code.

### LG KP265

1. Use Original SIM to switch ON the Phone.
2. Enter: 2945##265#
3. Then go to MENU > SETTINGS > SECURITY
4. Then go to SIM LOCKS > NETWORK > DEACTIVATE
5. Enter: NCKUnlockCode and press OK.

### LG ME550

1. Use Original SIM to switch ON the Phone.
2. Enter: 2945##71101#
3. Menu will appear, go to Settings > Security > SIM Lock
4. Enter: NCKUnlockCode and press OK.

### LG TU915

1. Switch ON your phone with an allowed SIM Card
2. Enter: 2945##9701#
3. It should ask you for the Unlock Code.

OR

1. Enter \*#865625# then enter your 16 digit code.

### LG KF390 and KF390q

1. Insert a SIM Card from the network the mobile is locked to and turn the phone on.
2. Enter: \*#865625#
3. Select 'Unlock USIM'
4. Select 'Network Lock'
5. Enter the Unlock Code
6. Select ok.

### LG Prada, KE850

1. Switch the telephone on with original SIM card installed.
2. Enter SIM pin if required.

# Unlock Instructions by EarthWizeCellular.com

---

3. Enter: 2945##8501# and press the call button (middle button bottom of the screen).
4. SIM unlock mode will appear on screen.
5. Enter Unlock Code.
6. Select Reboot.
7. Switch phone off, and then turn back on again. Phone is now unlocked.

## **LG CT810**

1. Insert original SIM Card and turn phone on.
2. Enter: 2945##810#
3. A menu will pop up, select SIM Unlock.
4. Enter your Unlock Code, and press ok.
5. The phone will then reboot and the unlock is complete.

## **LG VU CU915 & CU920**

1. Put a AT&T or Cingular SIM Card in the phone; it does not have to be an active SIM Card.
2. Enter: \*#865625#UnlockCode
3. Device should say: Network Lock Deactivated
4. Phone may automatically reboot and is now unlocked.

## **LG U310**

1. Turn ON the phone without SIM Card .
2. Enter: 815118##
3. SIM Unlock Mode will pop up .
4. Enter your Unlock Code, and press ok.
5. The phone will then reboot and the unlock is complete.

## **LG KC550, KS360, KP230, KP500, KP501, KP270**

1. Insert original SIM Card and turn phone on.
2. Enter: 2945##71001#
3. SIM Unlock Mode will pop up.
4. Enter your Unlock Code, and press ok.
5. The phone will then reboot and the unlock is complete.

## **LG KF700 (aka LG Virgo)**

1. Insert original SIM Card and turn phone on.
2. Enter: 2945##700#
3. A menu will pop up, select SIM Unlock.
4. Enter your Unlock Code, and press ok.
5. The phone will then reboot and the unlock is complete.

## **LG KC910, KF910 (aka LG Prada)**

1. Insert original SIM Card and turn phone on.
2. Enter: 2945##910#
3. A menu will pop up, select SIM Unlock.
4. Enter your Unlock Code, and press ok.
5. The phone will then reboot and the unlock is complete.

# Unlock Instructions by EarthWizeCellular.com

---

## LG KF750

1. Insert original SIM Card and turn phone on.
2. Enter: 2945##750#
3. A menu will pop up, select SIM Unlock.
4. Enter your Unlock Code, and press ok.
5. The phone will then reboot and the unlock is complete.

## LG KF600

1. Insert original SIM Card and turn phone on.
2. Enter: 2945##71001#
3. SIM Unlock mode pop up .
4. Enter your Unlock Code, and press ok.
5. The phone will then reboot and the unlock is complete.

## LG U970

1. Insert original SIM Card and turn phone on.
2. Enter: 2945##970#
3. A menu will pop up, select Unlock SIM.
4. Select Network Lock.
5. Enter the unlock code and ok.

## LG U300

1. Switch ON the phone with Accepted SIM Card (from Original Network Provider).
2. Enter Code: 815118##
3. Phone will ask to enter NCK

## LG C2000

1. Insert Non-Cingular SIM card.
2. Power on the handset - phone will display "phone restricted"
3. Select "Cancel" - phone will display "phone restriction code"
4. Enter the Unlock Code.
5. Select "OK" - the handset is now successfully unlocked.

## LG KU990 Viewty & KE990

1. Insert original SIM Card and turn phone on.
2. Press telephone icon at bottom of screen to bring up the phone keypad.
3. Enter: 2945##990#
4. A menu will pop up, select SIM Unlock.
5. Enter your Unlock Code, and press ok.
6. The phone will then reboot and the unlock is complete.

## LG TU720 - LG CU720 and all LG Shine SERIES

1. Power ON your phone with an accepted SIM card.
2. Enter: ##865625#UNLOCK CODE
3. Press OK
4. Device is now unlocked.

# Unlock Instructions by EarthWizeCellular.com

---

## LG CE110

1. Put a Non - AT&T or Cingular SIM in the phone.
2. The phone display: Invalid Smart Chip.
3. Power on handset.
4. Select "Cancel" - phone displays "phone restriction code"
5. Enter the Unlock Code.
6. Select "OK" - the handset is successfully unlocked.

## LG CU400 & CU500v

1. Insert SIM Card from a unsupported network provider.
2. Power on the handset.
3. Phone will display "Invalid SmartChip"
4. In Idle screen, enter: 159753##
5. Phone will display "Enter NCK, Remaining 5"
6. Enter the 8 digit SIM Unlock Code
7. Select "OK"
8. The handset is now successfully unlocked.

## LG U8150

1. Switch ON your phone with a Non - Allowed SIM Card.
2. Enter: 277634##
3. Go to menu "SIM Lock".
4. Enter the Unlock Code we sent to you.

## LG U400

1. Insert the original network SIM in the handset.
2. Enter: 2945##88110#
3. The phone will then prompt 'Unlock SIM'. Press OK.
4. The phone will then prompt 'Network Unlock'. Press OK.
5. The phone will then prompt- 'Input Network Control Key'.
6. Enter the 8 digit unlocking code. Press OK. If the unlocking code comes with only 7 digits, add a 0 in front of the 7 digit code. If the unlocking code comes with only 6 digits, add 00 in front of the 6 digit code.
7. It should give you the message 'Success'.
8. Come back to the main screen and enter: 2945##88110#
9. The phone will then prompt 'Unlock SIM'. Press OK.
10. The phone will then prompt 'Network Unlock / Lock' but if you scroll down you will see a message Enter SP Lock.
11. Enter SP Code. Then press OK.

## All other Models

1. Switch ON your phone with an Allowed SIM Card.
2. Enter:

2945##5101# - (if you have a LG 510w)  
1945##5101# - (if you have a LG 1200 & B1200)  
2945##5221# - (if you have a LG 5200 & 52200)  
2945##5301# - (if you have a LG 5300)  
2945##5401# - (if you have a LG 5400)  
2945##70001# - (if you have a LG 7020)

# Unlock Instructions by EarthWizeCellular.com

---

2945##7101# - (if you have a LG 7100)  
2945##1201# or 2945##70001# - (if you have a LG 1100)  
2945##70001# - (if you have a LG7250T)  
2945##2201# - (if you have a LG C2200)  
2945##5301# - (if you have a LG T5100)  
2945##3311# - (if you have a LG C3310)

3. Go to "Menu" and then to "Settings".
4. Then select "Security".
5. To finish select "Network Provider" and select "Deactivate".
6. Enter the Unlock Code we sent to you.

## To Classify

For the next models you must insert the original SIM:

LG C3100 press 2945##3101#  
LG C3380 press 2945##7101#  
LG F2300 press 2945##7101#  
LG KE260 press 2945##2601#  
LG KE970 press 2945##9701#  
LG KG120 press 2945##1201#  
LG KG220 press 2945##1201#  
LG KG240 press 2945##3311#  
LG KG280 press 2945##7101#  
LG KG290 press 2945##7101#  
LG KG800 press 2945##7101#  
LG KU250 press 2945##250#  
LG KU380 press 2945##380#

After that will appear an secret menu. Go to Settings => Security- SIM Lock ,enter NCK and press OK.

For next models you must insert a Non – Acceptable SIM:

LG KU311 press 815118##  
LG KU800 press 82652##  
LG L600v press 815118##  
LG U8150 press 277634##  
LG U8210 press 277634##  
LG U8500 press 277634##  
LG U400 press 2945##88110#  
LG KC550 press 2945##71001#  
LG KU580 press 2945##580#  
LG KT520 press 2945##520#  
LG KF750 press 2945##750#  
LG KF600 press 2945##71001#  
LG KG275 press 2945##20001#  
LG KU380 press 2945##380#  
LG KU311 press 815118##  
LG KU800 press 82652##  
LG L600v press 815118##  
LG U8150 press 277634##  
LG U8210 press 277634##  
LG U8500 press 277634##

## Unlock Instructions by EarthWizeCellular.com

---

LG C3100 press 2945#\*3101#  
LG C3380 press 2945#\*7101#  
LG F2300 press 2945#\*7101#  
LG KE260 press 2945#\*2601#  
LG KG120 press 2945#\*1201#  
LG KG220 press 2945#\*1201#  
LG KG240 press 2945#\*3311#  
LG KG280 press 2945#\*7101#  
LG KS500 press 2945#\*500#  
LG KP270 press 2945#\*270#  
LG KF240 press 2945#\*240# or 2945#\*2401#  
LG KG290 press 2945#\*7101#  
LG KU250 press 2945#\*250#  
Enter NCK and press OK.

