

Unlock Instructions by EarthWizeCellular.com



How to enter my Unlock Code on a Sagem Cell Phone?

Sagem My-S7

1. Switch ON your phone without SIM Card.
2. Compose : `*##UnlockCode#` and press "Call" button.

All other Sagem

1. Switch ON your phone with a Non - Allowed SIM Card
2. Phone will show "SIM VERROU"
3. You can now enter the Unlock Code we sent to you.

WARNING : if your mobile show "CODE POSTE" it's because you have a Security Code, can be 0000 or 1234 but we can't determine this code with your IMEI because it's not code from Phone but code from the User of the Phone !

