

Unlock Instructions by EarthWizeCellular.com



How to enter my Unlock Code on a SonyEricsson Cell Phone?

All SonyEricsson

1. Switch ON your phone without a SIM Card.
2. Press the left arrow once.
3. Press the "*" button twice.
4. Press the left arrow once.
5. The message "Personalize with MNC2" will appear.
6. You can now enter the Unlock Code we sent to you.

NOTE: If your phone have a "JOGDIAL" (ex : SonyEricsson K700i) you must press "down arrow" instead of "left arrow" for step 2 & 3. By "Down Arrow" we mean to direct the Jogdial down.

